

# How to make a Big Board

**Supply List:** 2 foot by 4 foot piece of  $\frac{3}{4}$  inch plywood. This may be purchased precut at Home Depot or similar stores.  
Duct tape cut in several 6 to 8 inch strips  
Staple Gun (optional)  
Batting  
1½ yard of muslin fabric  
Dining table or other large work surface

1. Cut 2 to 4 pieces of batting depending on thickness desired 30 by 50 inches or enough to wrap around edges of board.
2. Place muslin flat on work surface.
3. Center batting over muslin. Muslin may be trimmed at this point to fit better.
4. Center plywood over batting
5. Avoiding lumps and keeping fabric taut, wrap muslin and batting to back of plywood and affix using staple gun or duct tape. This can be a one step or two step process. Work opposite sides first and then add extra tape/staples to corners.
6. Cover staples with duct tape to prevent future injury.
7. Place on regular ironing board and enjoy.

Approximate cost of plywood is \$15.00